



1. Insert dropper wire in front of fence wires
2. Dropper wire shown securing fence wire
3. Bend dropper wire around and
4. Through the hole
5. Wind dropper around fence wire securing both the Dropper wire and top Fence Wire



*Daveles is a registered trademark. Daveles steel Smartposts have design registrations & patents pending in New Zealand and Australia. Daveles is backed by Smartweld Limited (2006), supplying the local businesses with engineering solutions and spring manufacturing products for the garage door industry.*